

RUBANS POUR IMPRIMANTES MATRICIELLES

LEXMARK™

IBM

CODE		REF. BOITE	COND
3-138-60-0046	RUBAN 1040930 238X / 239X / 248X / 249X (4 millions de caractères)	1040930	1
C/1288	RUBAN 24XX (8 millions de caractères)	11A3550	1
3-138-60-0049	RUBAN 1040864 4226	1040864	1
3-138-60-0056	RUBAN 11A6150 4227	11A6150	1
3-138-60-0009	RUBAN 6295158 4234-2 modèle 01/02/03	6295158	1
3-138-60-0031	RUBAN 1040282 4234-12 modèle 07-08-09-10-11-12-13	1040282	1
3-138-60-0053	RUBAN 1053685 4247	1053685	1
C/1311	RUBAN 1040995 6400/6412 (30 millions de caractères)	1040995	1
C/781	RUBAN 1040990 6400/6408 (20 millions de caractères)	1040990	1
C/1193	RUBAN 39U2551 6500 (50millions de caractères)	39U2551	1



EPSON®

C/661	RUBAN S015013 DLQ 2000	S015013	1
C/274	RUBAN S015086 LQ 2070/2170/2180	S015086	1
C/895	RUBAN S015329 FX890	S015329	1
3-138-10-0216	RUBAN 7753 LQ 450/500/510/550/570/570+/80/850/850+/870/Act. Print.4000/5000	7753	1
3-138-10-0214	RUBAN 7754 LQ 1000 / 1010 / 1050 / 1050+ / 1070 / FX 1170	7754	1
3-138-10-0215	RUBAN 8750 LX300/800-LQ 500/800/850-FX870/880	8750	1
C/969	RUBAN 8755 FX1000/1050/1170	8755	1
3-138-10-0219	RUBAN 8766 DFX 5000/8000/8500	8766	1
C/366	RUBAN ERC22	ERC22	1
C/1323	RUBAN ERC31 TMU950	ERC31	1
3-138-10-0157	RUBAN ERC38P M300/TMU200-210-310-375	ERC31	1
C/1297	RUBAN ERC39 N/R	ERC38 NR	1



TALLY

3-138-10-0259	Pour T131/151 (2 millions de caractères)	0 52148011	1
3-138-10-0115	Pour T230/3XX/ T2055/2155/2070/2170/2265/2280	1250277	1
C/77	Pour T645/660/661/690/691/6045/6050/6082/6092 (50 mill. caractères)	0 8029604	1
C/438	Pour T2130 (4 millions de caractères)	0 44830	1
C/528	Pour T5023 (10 millions de caractères)	397995	1
C/1146	Pour T5040	43393	1
C/1388	Pour T6312	86043	1



brother

3-138-10-0220	RUBAN 4018	9060	1
3-138-10-0209	RUBAN M1824L/1818/1924L/19181809/1909	9090	1

OKI

C/171	RUBAN 172/182/182T/183/184T/192/193/280/320/321	0 9002303	1
3-138-10-0211	RUBAN 380/385/386/390/391/3390/3391	0 9002309	1
C/224	RUBAN ML520/521	0 9002315	1

